



1. P-Iris socket
2. RJ-45 socket
3. Power socket
4. Reset button
5. Micro-SD card slot
6. Video Out socket
7. GND socket
8. Alarm socket
9. Audio Out socket
10. Audio In socket
11. Reset button